

Purity Prime Pre-Installation Checklist

Thank you for being a Culligan Quench customer! We are excited for your workplace to experience the great-tasting water from your new Purity Prime. Before our certified technician can install your machine, the following pre-installation requirements must be completed.

Water Supply

- Cold potable water supply only
- Minimum water pressure 40 PSI; Maximum water pressure 60 PSI
 - Plumbing water supply connection with angle stop valve 3/8" O.D. compression outlet
 - Any water line or valve less than 1/4" is not acceptable
- Water shut-off valve must be in good working condition

Electrical

- Culligan Quench recommends a dedicated 120 VAC/60Hz/4 amp (standard 3-prong) electrical circuit
- Must be within 6' of machine location; **NO EXTENSION CORDS**

Connectivity

- **Cellular Connectivity:** A minimum of 3 bars of cellular connectivity is recommended for C-Sense™ connectivity
 - AT&T and Verizon are the preferred cellular carriers
- **Wi-Fi Connectivity:** Confirm availability and permissions to a non-captive internet connection. Office champion or IT personnel will need SSID (Wi-Fi name) and password at installation for C-Sense™ connectivity
 - Non-captive Wi-Fi connectivity means the device can connect automatically without requiring any manual steps, such as clicking a confirmation button or entering additional login details on a pop-up screen.
 - Culligan Quench Service Technicians are not permitted to enter customer Wi-Fi details.

Placement

- **PurityPrimeFS:** has a footprint of 12.6" w x 21.28" d
- **PurityPrimeCT:** has a footprint of 15" w x 20.4" d
 - Under counter space may be required to install CO₂ tank
 - The countertop model requires minimum 3/8" to 1" diameter hole for the water line to the machine
 - Culligan Quench technicians are only permitted to drill up to 2" diameter holes through laminate or Corian counters. Any other surface or hole size must be pre-drilled prior to install.

Ventilation

- Requires 1" clearance on either side with 2" in the back for ventilation
- At least 3" clearance is required on the top of the machine for ventilation

CO₂ Supply

- CO₂ cylinder is on-site
 - Culligan Quench service technician will typically deliver CO₂ for installation; confirm with your Culligan Quench Water Expert
 - A 10lb. tank of CO₂ fits inside the base of the Purity Prime
- For optimum performance, Culligan Quench requires using CO₂ cylinders and does not accept connecting to a bulk CO₂ system
 - Minimum CO₂ pressure is 55 PSI

If you have any
questions about
the installation,
call Customer
Care at
888-554-2782

Purity Prime FS



Purity Prime CT

Check out our Informational
Installation video for more details:
<https://vimeo.com/675531080>

Culligan Quench Installation Standards

Culligan Quench machines are expertly installed by a team of more than 200+ of our own Culligan Quench-trained technicians located across the U.S. Culligan Quench technicians follow industry best practices for all of our water cooler, ice machine, coffee brewer, and filtration system installations, and benefit from ongoing training provided by our technical education team and manufacturing partners. Culligan Quench installations include:

1. Water Quality Testing:

Culligan Quench will test your water supply for Total Dissolved Solids (TDS), the measurement of small organic and inorganic particles in the water. If the TDS level is over 250 ppm (parts per million) Culligan Quench generally recommends reverse osmosis (RO) filtration.

The water pressure at the source will also be tested. If the pressure is more than 60 psi (pounds per square inch), the technician will install a pressure regulator (at no extra charge) to ensure that the water has sufficient contact time inside the filter.

2. Identification of Appropriate Water and Electrical Sources:

Our technician will identify a potable water source, like a sink, a water supply line that feeds a hot water heater, or water line in your ceiling that is within 200 feet of the Culligan Quench machine. Culligan Quench does not tap into sprinkler or H/VAC lines. Culligan Quench machines must be installed within 6 feet of an electrical outlet.

3. Installation of Water Line from Source to Machine Location:

Culligan Quench uses high quality, food-grade tubing, either black polyethylene or polypropylene. Some communities' local plumbing codes may require the use of copper tubing, which Culligan Quench will provide at no extra charge.


The water line is run from the water source to your new Culligan Quench machine, and installed virtually invisibly: above ceilings, behind walls, or behind baseboard cove moldings.

A small hole is cut in the wall to connect the water line to the Culligan Quench machine, which the technician will cover with a wall plate (similar to those used for cable TV outlets).

4. Installation of Emergency Water Shut-Off Valve:

An emergency water shut-off (a ball valve) will be installed in an easily accessible spot near both your Culligan Quench machine and the water source.

Where plumbing codes require it, we will also install a backflow prevention device, which is a small valve to prevent water from your Culligan Quench machine from flowing back into the water line tubing.



5. Flushing of the Filter:

The technician will flush the carbon filter to ensure the unit has good flow and that any loose carbon particles are cleared.

6. Inspection to Ensure Proper Function:

After the installation is complete, the technician performs a multi-point inspection, including checking all lines and tanks, cold and hot water temperature settings, de-scaling ice machines and ice production, carbonation levels, and taste.



Emergency water shut-off

7. Demonstrate to you how to use your new Culligan Quench system